





For doors on escape routes

- The features of this panic device are of utmost importance for people's safety. Therefore in no case may any changes be made to the product.




Machining the profile

- After completing work on the profile, fasten the push bar in place using V3 screws provided (8 self-tapping screw, \varnothing 3,9mm. Drill a \varnothing 3,0 mm. hole.)








- After completing work on the profile, fasten the push bar in place using V3 screws provided (16 self-tapping screw, \varnothing 3,9mm. Drill a \varnothing 3,0 mm. hole.)


PHDT54 PHDT55





PHDT57



Fixing screws			
V1	3	Torx T20	
V2	6		



To reduce bar length






ATTENZIONE:



- Ensure all three bars are reduced by the same amount
- Use blade designed to cut stainless steel
- Cut at 90 degrees exactly

**PHDT54
PHDT55**

PHDT57



Fixing screws			
Fixing screws	Horizontal		Vertical
	Horizontal	Vertical	
V2		4	
V3	6	8	
D1		2	
G1		4	



Threaded rod

Rod Covers

